STANDARD ARRIVAL ROUTES – INSTRUMENT (STAR)

BERLIN/SCHÖNEFELD (NORTH) RWY 25R

Designator	Identification Significant Points	Mag (True) Track	Dist NM	MNM IFR Crusing Level	Remarks
1	2	3	4	5	6
BODLA 3V	**BODLA THREE VICTOR**				
	△ BODLA				1. BRNAV equipment necessary.
	△ RENKI	214 (217.0)	27.1	4000	2. Arrange your flight to cross TERDA max. FL 100.
	△ TERDA	188 (190.9)	6.5	4000	
RENKI 5V	**RENKI FIVE VICTOR**				
	△ RENKI				
	△ TERDA	188 (190.9)	6.5	4000	
GOLBO 2V	**GOLBO TWO VICTOR**				
	△ GOLBO				
	△ TERDA	146 (148.7)	21.9	4000	
BATEL 7V	**BATEL SEVEN VICTOR**				
	△ BATEL				1. BRNAV equipment necessary.
	△ GIRIT	064 (066.4)	38.9	4000	2. Arrange your flight to cross NASAT and TERDA max. FL 100.
	△ NASAT	087 (089.4)	45.4	4000	
	△ TERDA	086 (089.0)	21.9	4000	
VIBIS 4V	**VIBIS FOUR VICTOR**				
	△ VIBIS				1. BRNAV equipment necessary.
	△ PODUS	090 (092.9)	17.9	4000	2. Arrange your flight to cross TERDA max. FL 100.
	△ PINUV	090 (093.4)	29.6	4000	
	△ TERDA	122 (124.7)	12.5	4000	

© DFS Deutsche Flugsicherung GmbH